fp range



1-14 zone conventional fire alarm control panels and ancillaries





fp range

of 1-14 ZONE
CONVENTIONAL
FIRE ALARM
CONTROL PANELS

C-TEC's FP Range of conventional fire alarm control panels is one of the most robust and cost-effective available. Fully compliant with



BS 5839 part 4, the range encompasses no less than ten different variants, covering 1 to 14 zones.

The size, durability and flexibility of the range makes it ideal for use in all types of commercial and residential property including small shops, factories, schools, warehouses, offices and houses in multiple occupation.

Often referred to as 'the installer's choice', easy-to-follow wiring instructions are printed adjacent to the terminals of all variants and a lift-off lid guarantees an easy first fix and straightforward maintenance.

The panel's broad compatibility with virtually all known smoke and heat detector ranges and its ability to interpret a short circuit in any zone(s) as a fire or fault condition make it particularly useful for retro-installations.

An optional head removal facility (which utilises C-TEC's BF378 range of end-of-line monitoring units) is also available, making the FP fully compliant with the head removal requirements of BS 5839 part 1.

FP Range Features

- Fully compliant with BS 5839 Part 4
 - Lift-off lid for easy first fix and maintenance
 - Attractive easy-to-clean polycarbonate front label
 - Heavy-duty base connections
 - Robust metal lid and metal back box
 - Ultra-bright, long-life LED indicators
 - Built-in 24V power supply and battery charger
- Optional head removal facility for compliance with BS 5839 Part 1
- Compatibility with virtually all known conventional smoke and heat detector ranges
 - True three wire operation of sounder and detector circuits (Ov is common) for considerable cost savings on installation
- Separate indicators for open and short circuit fault, sounder fault and battery/power supply fault
- Non-latching 'class change' sounder input, latching fire and non-latching fault outputs (available via optional expansion loom)
- Fault buzzer mute facility
 - Space available for the rated capacity of VRLA batteries
- Short circuit = fire facility (pre-1980 BS, no resistors in call points), selectable on a zone by zone basis for retro-installations
- True battery monitoring circuit
- One man walk test and zone isolate facility (not available on EFP1)
- Ancillary connections for repeater panels and other system add- including fault relay modules, fire relay modules, sounder delay relay modules, sounder extender kits, etc (not available on EFP1)
- Easy to follow installation instructions and log book
- Multilingual variants available (subject to quantities)



Internal power supply	10% 50/60 H				
Internal power supply 27V d.c. nominal					
Total output current limited to 400mA @ 230 V a.c.					
Supply and battery charger monitored for failure Ves Yes Yes Yes Yes Yes Yes Ye	230 V a.c.				
Detector Circuit Specification	Yes				
Number of circuits 1 (EFP1, non-extendable) 2 (FP2, non-extendable) 4 (FP4, extendable to 6) 6 (FP6, non-extendable) 8 (FP8, ext. 10 (FP10, non-extendable) 8 (FP8, ext. 10 (FP10, non-extendable) 10 (FP10, non-ext	Yes				
Number of circuits 1 (EFP1, non-extendable) 2 (FP2, non-extendable) 4 (FP4, extendable to 6) 6 (FP6, non-extendable) 8 (FP8, ext. 10 (FP10, non-extendable) 8 (FP8, ext. 10 (FP10, non-extendable) 10 (FP10, non-ext					
A (FP4E, non-extendable) 6 (FP6, non-extendable) 10 (FP10, ex 8 (FP8E, non-extendable) 12 (FP12, ex 9 (FP8E, non-extendable) 12 (FP12, ex	andahla ta 14				
Line monitored for open and short circuit faults Ves Ves Ves Ves Ves Ves Ves Line monitored for head out/detector removed faults Ves - if optional BF378 or BF378M End of Line Monitoring unit (not supplied) 6800 \(\Omega \) % Tol. 0.25 W 6800 \(\Omega \) 6800 \(\Omega \) % Tol. 0.25 W 6800 \(\Omega \) 6800 \(\Omega \) 6800 \(\Omega \) % Tol. 0.25 W 6800 \(\Omega \) 6800 \(\Omega	tendable to 14 tendable to 1 tendable to 1 on-extendable				
Line monitored for head out/detector removed faults End of line resistor value (supplied) 6800 2 5% Tol. 0.25W 6800 2 5% Tol. 0.25W 6800 2 5% Tol. 0.25 W 70 - 6800 2 5% Tol. 0.25 W 70 - 6800 2 5% Tol. 0.25 W 70 - 6800 2 5 W 7					
End of line resistor value (supplied)	Yes				
Silicon 1N4001 or Schottky type (required if BF378 or BF378M End of Line Monitoring is fitted to show head out failty.	of line resist				
Call point resistor value (not supplied) A70 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \(\omega 470 - 680 \(\Omega 0.5 \) \\ \(\omega 0.5 \) \(\omega 0.5	6 Tol. 0.25 W				
Call point resistor value (not supplied) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 470 - 680 \(\Omega \) 0.5 \(\W \) 800 \(\Omega \) detector current 2mA) 20 \(\text{(max detector current 2mA)} \) 800	Silicon 1N4001 or Schottky type (required if BF378 or BF378M End of Line Monitoring Unit				
Max. number of detectors per zone No limit No limit No lim	30 Ω 0.5 W				
Max. number of manual all points per zone No limit Ro limit 8000 Ω 5% Tol. 0.25 W 6800 Ω 5% Tol. 0.25 W 68	tor current 2m				
Number of circuits 2	limit				
Number of circuits 2					
Heavy duty Niglon-type, largest acceptable conductor size 2.5mm²	2				
End of line resistor value 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 6800 \(\Omega \) 5% Tol. 0.25 \(\Omega \) 70 Tol. 70 Tol					
Line monitored for open and short circuit faults Ves Yes Yes Yes Outputs fused at 400mA 1A 1A Max. total output current to all outputs 400mA 800mA 1.4A Max. number of bells at 25mA 16 32 56 Max. number of sounders at 20mA 20 40 70 Volt free relay contacts (active when sounders active) Navailable via optional expansion looms (not supplied) Class change input, fire output and fault output via EFPX loom Fuses (to IEC - EN60127 Pt2) Mains terminal block 125mA T 20mm 400mA T 20mm 400mA T 20mm 400mA T 20mm 400mA T 20mm 630m. Sounder outputs 400mA F 20mm (F1, F2) 11A F 20mm (F2, F3) 11A F 20mm (F2, F3) 11A F 20mm (F4) 11A F 20mm (F4) 11A F 20mm (F1) 11A F 20mm (F2) 11A F 20mm (F2	/ Tal 0 25 M/				
Outputs fused at ### 400mA ###	Yes				
Max. total output current to all outputs 400mA 800mA 1.4A Max. number of bells at 25mA 16 32 56 Max. number of sounders at 20mA 20 40 70 Volt free relay contacts (active when sounders active) n/a Yes, 1A 30V d.c. max Yes, 1A 50V d.c. max Yes, 1A 30V d.c. max Yes, 1A 30	.6A				
Max. number of bells at 25mA 16 32 56 Max. number of sounders at 20mA 20 40 70 Volt free relay contacts (active when sounders active) N/a Ves, 1A 30V d.c. max Yes, 1A 50V d.c. max Yes, 1A 30V d.	3A				
Max. number of sounders at 20mA 20 40 70 Volt free relay contacts (active when sounders active) N/a Yes, 1A 30V d.c. max Yes, 1A	120				
Volt free relay contacts (active when sounders active) Na	150				
Auxiliary Inputs / Outputs Available via optional expansion looms (not supplied) Class change input, fire output and fault output are also available (1 per panel instead of FPX loom) Fuses (to IEC - EN60127 Pt2) Mains terminal block 125mA T 20mm 200mA T 20mm 400mA T 20mm 630m. Sounder outputs 400mA F 20mm (F1, F2) 1 A F 20mm (F2, F3) 1 A F 20mm (F2, F3) 1 A F 20mm (F4) 1 A F 20mm (F4) 1 A F 20mm (F4) 1 A F 20mm (F1) 200mA T 20mm 400mA T 20mm 630m. 6	OV d.c. max				
Available via optional expansion looms (not supplied) Class change input, fire output and fault output are also available (1 per panel instead of FPX loom) FUSES (to IEC - EN60127 Pt2) Mains terminal block 125mA T 20mm 200mA T 20mm 400mA T 20mm 630m. Sounder outputs 400mA F 20mm (F1, F2) 1A F 20mm (F2, F3) 1A F 20mm (F2, F3) 1A F 20mm (F4) 1A F 20mm (F1) Auxiliary output 1A F 20mm (F3) 1A F 20mm (F1) 1A F 20mm (F1) 1A F 20mm (F1) Auxiliary fuse 1A F 20mm (F1) Auxiliary output Na					
fire output and fault output via EFPX loom Fuses (to IEC - EN60127 Pt2) Mains terminal block 125mA T 20mm 200mA T 20mm 400mA T 20mm 630m. Sounder outputs 400mA F 20mm (F1, F2) 1A F 20mm (F2, F3) 1A F 20mm (F2, F3) 1A F 20mm (F4) 1A F 20mm (F4) 1A F 20mm (F1) Battery fuse 1A F 20mm (F1) The panel Indicators Mains On; Zone Fire; Zone Fault; Sounder Fault; Battery/Power Supply Fault Internal Indicators O/C Fault; S/C Fault Sounders; Evacuate Feset; Silence Alarm/Fault Sounders; Evacuate Revert to short circuit = fire; One man detector test; Zone Revert to short circuit = fire; One man detector test; Zone					
Mains terminal block 125mA T 20mm 200mA T 20mm 400mA T 20mm 630m. Sounder outputs 400mA F 20mm (F1, F2) 1A F 20mm (F2, F3) 1A F 20mm (F2, F3) 1A F 20mm (F2, F3) 1.6A F 20mm (F4) 1A F 20mm (F4) 1A F 20mm (F4) 1A F 20mm (F4) 1A F 20mm (F1) 3A F 2 Panel Indicators and Controls External indicators Mains On; Zone Fire; Zone Fault; Sounder Fault; Battery/Power Supply Fault Internal Indicators O/C Fault; S/C Fault O/C Fault; S/C fault; Zone Isolated; Engineer Test Sele External controls (keyswitch operated) Reset; Silence Alarm/Fault Sounders; Evacuate Revert to short circuit = fire; One man detector test; Zone Revert to short circuit = fire; One man detector test; Zone	Class change input, zone 1 & zone 2 fire outputs, fault output and reset output via FPX loom. Self-contained fire, fault & sounder delay relay modules are also available (1 per panel instead of FPX loom)				
Sounder outputs 400mA F 20mm (F1, F2) 1A F 20mm (F2, F3) 1A F 20mm (F4) 1A F 20mm (F4) 1A F 20mm (F4) 1A F 20mm (F4) 1A F 20mm (F1) 1A F 20mm (F2) 1A F 20mm (F2) 1A F 20mm (F2) 1A F 20mm (F3) 1A F 20mm (F4) 1A F 20mm (F1) 3A F 2 Panel Indicators and Controls External indicators Mains On; Zone Fire; Zone Fault; Sounder Fault; Battery/Power Supply Fault Internal Indicators O/C Fault; S/C Fault O/C Fault; S/C fault; Zone Isolated; Engineer Test Sele External controls (keyswitch operated) Reset; Silence Alarm/Fault Sounders; Evacuate Silence Fault Sounders Internal controls Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone					
Sounder outputs 400mA F 20mm (F1, F2) 1A F 20mm (F2, F3) 1A F 20mm (F4) 1A F 20mm (F1) 3A F 2 Panel Indicators and Controls External indicators Mains On; Zone Fire; Zone Fault; Sounder Fault; Battery/Power Supply Fault Internal Indicators O/C Fault; S/C Fault O/C Fault; S/C fault; Zone Isolated; Engineer Test Sele External controls (keyswitch operated) Reset; Silence Alarm/Fault Sounders; Evacuate Silence Fault Sounders Internal controls Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone	A T 20mm				
Auxiliary output n/a 1A F 20mm (F4) 1A F 20mm (F1) 1A F 20	mm (F2, F3)				
Battery fuse 1A F 20mm (F3) 1.6A F 20mm (F1 1.6A F 20mm (F1) 3A F 2 Panel Indicators and Controls External indicators Mains On; Zone Fire; Zone Fault; Sounder Fault; Battery/Power Supply Fault Internal Indicators O/C Fault; S/C Fault O/C Fault; S/C fault; Zone Isolated; Engineer Test Sele External controls (keyswitch operated) Reset; Silence Alarm/Fault Sounders; Evacuate Silence Fault Sounders Internal controls Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone	0mm (F4)				
External indicators Mains On; Zone Fire; Zone Fault; Sounder Fault; Battery/Power Supply Fault Internal Indicators O/C Fault; S/C Fault O/C Fault; S/C fault; Zone Isolated; Engineer Test Sele External controls (keyswitch operated) Reset; Silence Alarm/Fault Sounders; Evacuate Silence Fault Sounders Internal controls Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone	0mm (F1)				
External indicators Mains On; Zone Fire; Zone Fault; Sounder Fault; Battery/Power Supply Fault Internal Indicators O/C Fault; S/C Fault O/C Fault; S/C fault; Zone Isolated; Engineer Test Sele External controls (keyswitch operated) Reset; Silence Alarm/Fault Sounders; Evacuate Silence Fault Sounders Internal controls Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone					
Internal Indicators O/C Fault; S/C Fault O/C Fault; S/C fault; Zone Isolated; Engineer Test Sele External controls (keyswitch operated) Reset; Silence Alarm/Fault Sounders; Evacuate Internal controls Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone					
External controls (keyswitch operated) Reset; Silence Alarm/Fault Sounders; Evacuate Reset/ Resound/Test Zone Lamps; Evacuate; Silence Alarm Silence Fault Sounders Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone	· · · · · · · · · · · · · · · · · · ·				
Sounders; Evacuate Silence Fault Sounders Internal controls Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone					
Internal controls Revert to short circuit = fire Revert to short circuit = fire; One man detector test; Zone	ouriders,				
Dimensions	isolate				
DITIENSIONS					
Approx dimensions of enclosure (M v H v D) 271 v 200 v 70mm 222 v 247 v 20mm 405 v 247 v 20mm 521 v 24	4 v 140mm				
	4 x 140mm				
Weight (without batteries) 2.3 kg 4.3kg 5.0 kg	2 kg				
Repeater Specification					
Max. number of repeaters n/a Three repeaters per main panel. Repeaters are available with 10 or 2					
Repeater wiring n/a Five control wires plus one extra wire per zone being repeated max cable length 200m	Five control wires plus one extra wire per zone being repeated; max cable length 200m				
Battery Stand-By Times EFP1 FP2 FP4E FP4 FP6 FP8E FP8 FP10 FP12	FP14				

FP2 FP12 FFP1 FP4F FP4 FP6 FP8F FP8 FP10 FP14 Quiescent current 25mA 40mA 50mA 50mA 60mA 70mA 70mA 80mA 90m 100mA Max. load current 0.4A 0.8A 0.8A 1.4A 1.4A 1.4A 3.0A 3.0A 3.0A 3.0A Stand-by time in hours using 1.2 Ahr batteries 48 40 32 Stand-by time in hours using 2.0 Ahr batteries 80 26 55 90 32 55 44 72 27 Stand-by time in hours using 2.6 Ahr batteries 38 47 36 31 28 25 Stand-by time in hours using 4.0 Ahr batteries 66 Stand-by time in hours using 6.0 Ahr batteries 106 88 75 64 56 50 45 Stand-by time in hours using 10.0 Ahr batteries 121 106 85

The quiescent current given is for the following conditions - mains supply failed, fault beeper muted, no aux. output connections, detector and sounder end of line devices fitted, no other loads supplied by the panel. The battery stand-by times are guidelines only based on the above conditions and a full sounder load for 30 minutes. Additional loads that increase the quiescent current in the normal state must be considered when calculating stand-by time. The fault beeper being active will add 10mA and reduced sounder loads will increase the stand-by time. Batteries in poor condition greatly reduce stand-by time.

the fp range

of 1-14 zone conventional fire alarm control panels and ancillaries





FP Range Panels

FF380-2	EFP1 single zone fire panel, does not extend	FF390-2	FP 10 zone fire panel, extends to 14 zones
FF382-2	FP 2 zone fire panel, does not extend	FF392-2	FP 12 zone fire panel, extends to 14 zones
FF384-3	FP 4 zone economy fire panel, does not extend	FF394-2	FP 14 zone fire panel, does not extend
FF384-2	FP 4 zone fire panel, extends to 6 zones	FF387Z-2	FP 2 zone extender PCB kit
FF386-2	FP 6 zone fire panel, does not extend		(use to increase number of zones on FP panels)
FF388-3	FP 8 zone economy fire panel, does not extend	FF396-2	FP 10 zone repeater panel
FF388-2	FP 8 zone fire panel, extends to 14 zones	FF398-2	FP 20 zone repeater panel

FP Range Ancillaries

FF374X	FPX expansion loom (not compatible with EFP1)	BF379	Schottky diodes, 10 pack (BYV1060/SR160)
FF374FR	FP fault relay module (not compatible with EFP1)	FF502P	Four zone sounder extender kit
FF374DFR	FP fire relay module (not compatible with EFP1)	FF379	Flush bezel for use with FP2 and FP4E panels
FF374DT	FP sounder delay module (not compatible with EFP1)	FF385	Flush bezel for use with FP4, FP6, FP8E
FF380X	EFPX expansion loom (for use with EFP1 only)		and FP repeater panels
BF378	EMU end of line 'head out' monitoring unit	FF387	Flush bezel for use with FP8, FP10, FP12
BF378M	MIMIMU miniature end of line 'head out'		and FP14 panels
	monitoring unit	Note: The E	EFP1 is designed to be surface mounted only

Battery Packs

BC283/2	24V 1.2 AmpHr battery pack
BC284/2	24V 2.1 AmpHr battery pack
BC285/2	24V 2.8 AmpHr battery pack
BC286/2	24V 7.0 AmpHr battery pack

DISTRIBUTED BY

Manufactured by C-TEC, Stephens Way, Wigan, WN3 6PH United Kingdom.

UK Sales Desk: Tel: 01942 322744 Fax: 01942 829867

EXPORT Sales Desk: Tel: +44 161 257 2541 Fax: +44 161 225 8817 Website: www.c-tec.co.uk





Quality System Certificate No: 176 Assessed to ISO9001 : 1994